

### **Limited Warranty**

This Wall Panel Heater was manufactured and tested according to the most strict modern requirements and standards.

**Please claim any warranty repairs with our Customer Service during the Warranty Period. Please keep the original packaging to properly ship the defective units to us.**

The manufacturer is not responsible for any physical damage and damage to others that is caused by an improper use or installation that is not described by this User's Guide. The warranty is void as a result of any improper use or an improper installation not described by this User's Guide.

**This Wall Panel Heater MAY NOT BE disassembled, damaged or changed in any way. Such attempt immediately causes the cancellation of Manufacturer's Warranty.**

Please contact our Customer Service in case of any malfunction, to rule out any external causes, before you send the Wall Panel Heater for any repair.

**The Warranty of the eco2heat® Wall Panel Heater is 36 Months since the day of the purchase. Please keep any original receipts as a proof of purchase.**

Eco2Heat LLC  
Customer Service  
426 Main Street #138  
Spotswood, NJ 08884  
732-723-8813  
[info@eco2heat.us](mailto:info@eco2heat.us)  
[www.eco2heat.us](http://www.eco2heat.us)



# Installation and User's Guide

# Infrared Wall Panel Heater

Thank you for choosing an **eco2heat®** product – the source of the most effective, efficient, pleasant, and healthy heat!

We hope you will enjoy our product for many years.

**Please read the following User's Guide before installation and the first use.**

### **Safety Measures**

Please keep any children away from this Wall Heater, unless they are constantly supervised.

#### **WARNING:**

**Certain parts may become hot during the normal operation and cause burns during the prolonged contact. Please supervise any children or disabled persons, to avoid any burns.**

**WARNING:** This heater is not equipped with any electronic device to control the room temperature. Please use this appliance with a plug-in or a line-voltage thermostat. You may not use it in the small rooms that are occupied by anyone who requires assistance in turning the heater off or may not be able to leave the room on her own, unless they are constantly being supervised.

1) The wall panel heater may only be wall mounted, according to the instructions provided in the Installation – section of this User's Guide, using the described hardware and included mounting brackets.

2) **DO NOT COVER this wall panel heater when it is in use, to avoid overheating**

3) DO NOT TURN THE HEATER ON OR USE IT in a HORIZONTAL POSITION on the floor, SIT or LEAN on it.

4) DO NOT USE THIS HEATER NEXT TO THE flammable materials or fuel.

5) DO NOT USE THIS HEATER to dry any wet clothing, linens, or shoes.

6) DO NOT EVER place any wet linens or clothes DIRECTLY ON THE TOP of the heater! Keep any materials **at least 3 feet away**.

6) DO NOT USE this heater to warm up any liquids or submerge it.

7) Protect the front of this heater from any physical damage. IMMEDIATELY STOP using the heater in case the front panel is cracked or otherwise visibly damaged.

8) Avoid touching the front panel of the heater. Although it is safe to touch and may not cause burns upon a short contact, its surface temperature is very hot.

9) Do NOT PLACE this heater immediately near or above a bathtub, shower or a sink.

### **Installation**

This Wall Panel Heater may only be mounted using the provided hardware.

Please keep the heater at least **3 feet away** from any furnishings or drapery.

1) PLEASE DO NOT EVER MOUNT this heater without the provided mounting brackets.

2) THE BOTTOM EDGE of the heater has to be at least 10 inches above the floor level.

3) THE TOP EDGE has to be at least 6 inches away from any shelving or cabinets mounted above.

4) You MAY NOT plug this wall panel into a plug positioned immediately behind the unit..

5) The wall plug has to be accessible at all times.

6) Mount this Wall Panel Heater on the walls with an electric outlet / junction box or use an appropriately rated extension cord.

### **Cable Replacement**

In case of any cable defect immediately stop using this Wall Panel heater, turn off the electric power to the device and contact our Customer Service at 732-723-8813.

### **Operation**

Plug the Wall Panel heater in. To control the room temperature, your comfort level and/or the on/off time, we recommend using it with either a plug-in thermostat, a programmable timer or a line-voltage thermostat.

### **Cleaning and Maintenance**

Please follow the below recommendations to ensure the long life of this Wall Panel Heater.

Turn the heater off and clean the surface of this Wall Panel Heater with a dry soft towel. Do not use any abrasive or other chemical cleaning detergents that could damage the ceramic surface.

### **Storage**

Please store this heater in a dry place with a ambient temperature above freezing.

### **Technical Data:**

Voltage and Frequency: 110 Volt or 220V (as marked on the back panel), 50/60 Hz

Operating Power:

<b>Type 50100 SKWH</b>	110V,480 Watt	(+5% -10%)
<b>Type 50100 SKWH</b>	220V,480 Watt	(+5% -10%)
<b>Type 5075 SKWH</b>	220V,410 Watt	(+5% -10%)
<b>Type 5050 SKWH</b>	220V,250 Watt	(+5% -10%)
<b>Type 60200 SKWH</b>	220V, 630 Watt	(+5% -10%)
<b>Type 60200 SKWH</b>	220V,1060 Watt	(+5% -10%)

Surface Temperature:

~ 167 - 180F (75 - 80C)

*Indoor Usage Only!*

### **Enclosed:**

Infrared Wall Panel Heater with attached cable, mounting brackets, mounting hardware, User's Guide.

**This Wall Panel Heater is certified by TÜV Rheinland, according to the following test codes:**

EN 60335-1:2012 + A11

EN 60335-2-30:2009 + A11

### **EMV Test:**

EN 55014-1:2006, EN 61000-3-2:2006

EN 61000-3-3:1995+A1:2001+A2:2005

EN 55014-2:1997+A1:2001



**Made in Germany**

